


Changing the input level

Mode	Display
P-manual mode Change position using ∇/Δ	<p>Potentiometer setting [%]</p> <p>Not initialized (can be reached using preset)</p> <p>Parameter value</p> <p>Parameter number</p> <p>Parameter name</p>
Manual mode Change position using ∇/Δ	<p>Position [%]</p> <p>Error code</p> <p>Mode and Setpoint [%]</p> <p>Position [%]</p> <p>Error code</p> <p>Mode and Setpoint [%]</p> <p>Diagnosis value</p> <p>Diagnosis number</p> <p>Diagnosis name</p>
Automatic mode Change position using ∇/Δ	<p>Position [%]</p> <p>Error code</p> <p>Mode and Setpoint [%]</p> <p>Position [%]</p> <p>Error code</p> <p>Mode and Setpoint [%]</p> <p>Diagnosis value</p> <p>Diagnosis number</p> <p>Diagnosis name</p>

(The gray values in the top display line are examples)

Configuring



Automatic initial start-up (starting with factory setting)

Step	Meaning
1.) Rotary actuator Linear actuator	<p>8888 84 YFCT</p> <p>8888 82 YFEL</p> <p>8888 53 IDENT</p> <p>8888 84 YFCT</p> <p>8888 82 YFEL</p> <p>8888 53 IDENT</p> <p>Press for > 5 s</p> <p>Remaining steps carried out automatically</p>
2.)	<p>8888 84 INITA</p> <p>Direction of action is determined</p>
3.)	<p>8888 84 RUN 1</p> <p>8888 84 RUN 2</p> <p>8888 84 RUN 3</p> <p>8888 84 RUN 4</p> <p>8888 84 RUN 5</p> <p>8888 84 FINISH</p> <p>Checking of travel and adjustment of zero and stroke (from stop to stop)</p> <p>Determination and Display of positioning time down (dxx.x), up (uxx.x) Stop with Pressing the Δ key initiates leakage measurement</p> <p>Determination of minimum increment length</p> <p>Optimization of transient response</p> <p>Initialization terminated successfully (travel in mm for linear actuators) (angle of rotation for part-turn actuators)</p> <p>Continue using: Δ</p>

Possible messages

Display	Meaning	Measures
<p>8888 84 RUN 1</p> <p>8888 84 ERROR</p>	Actuator does not move	<p>Acknowledge message using Δ</p> <p>Check restrictor (6) and open if necessary</p> <p>Drive actuator to working range using ∇/Δ</p> <p>Restart initialization</p>
<p>8888 53 IDENT</p>	Down tolerance band violated	<p>Change gearing (7)</p> <p>Continue using Δ or adjust sliding clutch to display</p>
<p>8888 84 YFCT</p> <p>8888 82 YFEL</p>	Once the slipping clutch has been adjusted	<p>Continue using Δ or for "WAY" using: Δ</p> <p>Linear actuator: Set pick-up lever into vertical position using ∇/Δ</p> <p>Continue using Δ</p>
<p>8888 84 UP ?</p>	Up tolerance band violated	<p>Acknowledge message using Δ</p> <p>Set the next highest travel value on the lever</p> <p>Restart initialization</p> <p>Additionally possible with rotary actuators: Adjust using ∇/Δ up to display: Δ</p> <p>Continue using Δ</p>
<p>8888 84 UP ?</p>	Up/down span insufficient	<p>Acknowledge message using Δ</p> <p>Set the next lowest travel value on the lever</p> <p>Restart initialization</p>
<p>8888 84 NOZZL</p> <p>8888 84 NOZZL</p>	Actuator does not move Positioning time is possible to adjust	<p>Adjust positioning time using restrictor(s)</p> <p>Continue using Δ or Δ</p>
See Manual for further messages		

Parameter name	Function	Parameter values (Bold = factory setting)	Unit
1.YFCT	Type of actuator	turn (part-turn actuator) WAY (linear actuator) LWAY (linear actuator without sine correction) ncSt (part-turn actuator with NCS) -ncSt (ditto, inv. direction of action) ncSL (linear actuator with NCS) ncSLL (ditto, and lever)	
2.YAGL 1)	Rated angle of rotation of feedback Set transmission ratio selector (7) appropriately (see view of device)	33° 90°	Degrees
3.YWAY 2)	Stroke range (optional setting) If used, the value must correspond with the set of the leverage ratio on the actuator Driver pin must be set to the value of the actuator travel or, if this value is not scaled, to the next larger scale value.	OFF ----- 5 10 15 20 (short lever 33°) ----- 25 30 35 (short lever 90°) ----- 40 50 60 70 90 110 130 (long lever 90°)	mm
4.INITA	Initialization (automatically)	noini no / ###.# Strt	
5.INITM	Initialization (manually)	noini no / ###.# Strt	
6.SDIR	Setpoint direction	riSE FALL	rising falling
7.TSUP	Setpoint ramp up	Auto / 0 ... 400	s
8.TSDO	Setpoint ramp down	0 ... 400	s
9.SFCT	Setpoint function	Linear Equal-percentage 1:25, 1:33, 1:50 Inverse equal-percentage 1:25, 1:33, 1:50 Freely adjustable	
10.SL0 3) 11.SL1 et. up to 29.SL19 30.SL20	Setpoint turning point at 0% 5% to 95% 100%	Lin 1 - 25 1 - 33 1 - 50 n1 - 25 n1 - 33 n1 - 50 FrEE	%
31.DEBA	Dead band of controller	Auto / 0.1 ... 10.0	%
32.YA	Start of manipulated variable limiting	0.0 ... 100.0	%
33.YE	End of manipulated variable limiting	0.0 ... 100.0	%
34.YNRM	Standardization of manipulated variable	To mech. travel To flow	
35.YCLS	Tight closing with manipulated variable	Without uP do Bottom only Top and bottom uP do	
36.YCDO	Value for tight closing, bottom	0.0 ... 100.0	%
37.YCUP	Value for tight closing, top	0.0 ... 100.0	%
38.BIN1 4)	Function of BI 1 None Only message Block configuring Drive valve to position YE Drive valve to position YA Block movement Partial-Stroke-Test	OFF on -on bLoc1 bLoc2 uP -uP doWn -doWn StoP -StoP PST -PST	NO contact NC contact
39.BIN2 4)	Function of BI 2 None Only message Drive valve to position YE Drive valve to position YA Block movement Partial-Stroke-Test	OFF on -on uP -uP doWn -doWn StoP -StoP PST -PST	NO contact NC contact
40.AFCT 5)	Alarm function Without A1=min, A2=max A1=min, A2=min A1=max, A2=max	OFF normal Π, ΠΠ Π̄, Π̄Π̄ Π, ΠΠ Π̄, Π̄Π̄ ΠΠ ΠΠ Π̄Π̄ Π̄Π̄ inverted	
41.A1	Response threshold of alarm 1	0.0 .. 10.0 .. 100.0	%
42.A2	Response threshold of alarm 2	0.0 .. 90.0 .. 100.0	%
43.YFCT 5)	on fault Fault + not automatic Fault + not automatic + BI ("+" means logical OR operation)	normal 4 4nΠ 4nΠb -4 -4nΠ -4nΠb inverted	
44.YTIM	Monitoring time for fault message "control deviation"	Auto / 0 ... 100	s
45.YLIM	Response threshold for fault message "control deviation"	Auto / 0 ... 100	%
46.YSTRK	Limit for stroke integral	0 ... 1.00E9	
47. PRST	Preset (factory setting) "no" nothing activated "Strt" start of factory setting after pressing key for 5s "oCAY" display following successful factory setting CAUTION: preset results in "NO INI"	no Strt oCAY	
48. XDIAG	Activating for extended diagnostics off single-stage alarm two-stage alarm three-stage alarm	OFF On1 6) On2 6) On3 6)	
49. FSTY	Safety position: parameterized safety setpoint last setpoint open venting valve	FSVL FSSP FSAC	
50. FSTI	Monitoring time for setting safety position	0 ... 100 (30)	s
51. FSVL	Safety setpoint	0.0 ... 100.0	%
52. STNR	Station number	0 ... 126	
53. IDENT	PROFIBUS ident number interchangeable to other positioner full functional range	0 1	

Parameter name	Function	Parameter values (Bold = factory setting)	Unit
A. 4 PST 6)	Partial-Stroke-Test with the following parameters:	0.0 ... 100.0 0.1 .. 2.0 .. 10.0 0.1 .. 10.0 .. 100.0 uP / do / uP do OFF / 1 ... 365 noini /(C)###/rEdInI/rEAL 0.1 .. 1.5 .. 100.0 0.1 .. 3.0 .. 100.0 0.1 .. 5.0 .. 100.0	% % % days s
A1. STPOS A2. STTOL A3. STEP A4. STEPD A5. INTRV A6. PSTIN A7. FACT1 A8. FACT2 A9. FACT3	Start position Start tolerance Step height Step direction Test interval Partial-Stroke-Test reference step time Factor 1 Factor 2 Factor 3		
b. 4 DEV 6)	Generally fault of valve with the following parameters:	Auto / 1 ... 400 0.0 .. 1.0 .. 100.0 0.1 .. 5.0 .. 100.0 0.1 .. 10.0 .. 100.0 0.1 .. 15.0 .. 100.0	s %
b1.TIM b2. LIMIT b3. FACT1 b4. FACT2 b5. FACT3	Time constant Limit Factor 1 Factor 2 Factor 3		
C. 4 LEAK 6)	Pneumatic leakage with the following parameters:	0.0 .. 30.0 .. 100.0 0.1 .. 1.0 .. 100.0 0.1 .. 1.5 .. 100.0 0.1 .. 2.0 .. 100.0	%
C1. LIMIT C2. FACT1 C3. FACT2 C4. FACT3	Limit Factor 1 Factor 2 Factor 3		
d. 4 STIC 6)	Stiction (Slip stick effect) with the following parameters:	0.1 .. 1.0 .. 100.0 0.1 .. 2.0 .. 100.0 0.1 .. 5.0 .. 100.0 0.1 .. 10.0 .. 100.0	%
d1. LIMIT d2. FACT1 d3. FACT2 d4. FACT3	Limit Factor 1 Factor 2 Factor 3		
E. 4 DEBA 6)	Monitoring for dead band with the following parameter:	0.0 .. 2.0 .. 10.0	%
E1. LEVEL3	Threshold		
F. 4 ZERO 6)	Zero shift with the following parameters:	0.1 .. 1.0 .. 10.0 0.1 .. 2.0 .. 10.0 0.1 .. 4.0 .. 10.0	% % %
F1. LEVEL1 F2. LEVEL2 F3. LEVEL3	Threshold 1 Threshold 2 Threshold 3		
G. 4 OPEN 6)	Shift of upper end stop with the following parameters:	0.1 .. 1.0 .. 10.0 0.1 .. 2.0 .. 10.0 0.1 .. 4.0 .. 10.0	% % %
G1. LEVEL1 G2. LEVEL2 G3. LEVEL3	Threshold 1 Threshold 2 Threshold 3		
H. 4 TMIN 6)	Monitoring for lower temperature limit with the following parameters: Temperature unit	°C / °F -40 ... 90 / -40 ... 194 -40 ... 90 / -40 ... 194 -40 ... 90 / -40 ... 194	
H1. TUNIT H2. LEVEL1 H3. LEVEL2 H4. LEVEL3	Temperature unit Threshold 1 Threshold 2 Threshold 3		
J. 4 TMAX 6)	Monitoring for upper temperature limit with the following parameters: Temperature unit	°C / °F -40 ... 90 / -40 ... 194 -40 ... 90 / -40 ... 194 -40 ... 90 / -40 ... 194	
J1. TUNIT J2. LEVEL1 J3. LEVEL2 J4. LEVEL3	Temperature unit Threshold 1 Threshold 2 Threshold 3		
L. 4 STRK 6)	Monitoring for stroke integral with the following parameters:	1 ... 1 000 000 0.1 .. 1.0 .. 40.0 0.1 .. 2.0 .. 40.0 0.1 .. 5.0 .. 40.0	
L1. LIMIT L2. FACT1 L3. FACT2 L4. FACT3	Limit of strokes Factor 1 Factor 2 Factor 3		
O. 4 DCHG 6)	Monitoring for direction change with the following parameters:	1 ... 1 000 000 0.1 .. 1.0 .. 40.0 0.1 .. 2.0 .. 40.0 0.1 .. 5.0 .. 40.0	
O1. LIMIT O2. FACT1 O3. FACT2 O4. FACT3	Limit of direction changes Factor 1 Factor 2 Factor 3		
P. 4 PAVG 6)	Calculation for average value of position with the following parameters:	0.5h / 8h / 5d / 60d / 2.5y ldLE / rEF./###.# / Strt 0.1 .. 2.0 .. 100.0 0.1 .. 5.0 .. 100.0 0.1 .. 10.0 .. 100.0	% % %
P1. TBASE P2. STATE P3.LEVL1 P4. LEVEL2 P5. LEVEL3	Time basis for average value Condition of calculation Threshold 1 Threshold 2 Threshold 3		

HINTS:

- Parameter appears only if "turn" or "WAY" is selected; at "turn", you cannot select 33°
- Parameter does not appear if "turn", "LWAY" or "ncS_" has been selected with YFCT
- Turning points only appear with selection SFCT = "FrEE"
- NC contact means: action with opened switch or Low level
NO contact means: action with closed switch or High level
- Normal means: High level without fault
Inverted means: Low level without fault
- Parameters A up to P only appears if parameter 48.XDIAG is activated with On1, On2 or On3. The contents of the parameters A up to P appears also only if the selected parameter is activated with On.