

SIEMENS

RUGGEDCOM MX5000RE

Installation Guide

Preface

Introduction

1

Installing the Device

2

Communication Ports

3

Technical Specifications

4

Dimension Drawings

5

Certification

6

03/2016

RC1060-EN-05

Copyright © 2016 Siemens Canada Ltd.

All rights reserved. Dissemination or reproduction of this document, or evaluation and communication of its contents, is not authorized except where expressly permitted. Violations are liable for damages. All rights reserved, particularly for the purposes of patent application or trademark registration.

This document contains proprietary information, which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Siemens Canada Ltd..

» Disclaimer Of Liability

Siemens has verified the contents of this document against the hardware and/or software described. However, deviations between the product and the documentation may exist.

Siemens shall not be liable for any errors or omissions contained herein or for consequential damages in connection with the furnishing, performance, or use of this material.

The information given in this document is reviewed regularly and any necessary corrections will be included in subsequent editions. We appreciate any suggested improvements. We reserve the right to make technical improvements without notice.

» Registered Trademarks

RUGGEDCOM™ and ROS™ are trademarks of Siemens Canada Ltd..

Linux® is the registered trademark of Linus Torvalds in the United States and other countries.

The registered trademark Linux® is used pursuant to a sublicense from LMI, the exclusive licensee of Linus Torvalds, owner of the mark on a world-wide basis.

Other designations in this manual might be trademarks whose use by third parties for their own purposes would infringe the rights of the owner.

» Security Information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit <http://www.siemens.com/industrialsecurity>.

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit <http://support.automation.siemens.com>.

» Warranty

Siemens warrants this product for a period of five (5) years from the date of purchase, conditional upon the return to factory for maintenance during the warranty term. This product contains no user-serviceable parts. Attempted service by unauthorized personnel shall render all warranties null and void. The warranties set forth in this article are exclusive and are in lieu of all other warranties, performance guarantees and conditions whether written or oral, statutory, express or implied (including all warranties and conditions of merchantability and fitness for a particular purpose, and all warranties and conditions arising from course of dealing or usage or trade). Correction of nonconformities in the manner and for the period of time provided above shall constitute the Seller's sole liability and the Customer's exclusive remedy for defective or nonconforming goods or services whether claims of the Customer are based in contract (including fundamental breach), in tort (including negligence and strict liability) or otherwise.

For warranty details, visit www.siemens.com/ruggedcom or contact a Siemens customer service representative.

» Contacting Siemens

Address

Siemens Canada Ltd.
Industry Sector
300 Applewood Crescent
Concord, Ontario
Canada, L4K 5C7

Telephone

Toll-free: 1 888 264 0006
Tel: +1 905 856 5288
Fax: +1 905 856 1995

E-mail

ruggedcom.info.i-ia@siemens.com

Web

www.siemens.com/ruggedcom

Table of Contents

Preface	vii
Alerts	vii
Related Documents	vii
Accessing Documentation	viii
Training	viii
Customer Support	viii
 Chapter 1	
Introduction	1
1.1 Feature Highlights	1
1.2 Description	2
1.3 Patch Panels	4
 Chapter 2	
Installing the Device	7
2.1 Assembling the MX5000RE	7
2.1.1 Installing the Power Supply Patch Cables	8
2.1.2 Installing the Chassis Ground Connection	11
2.1.3 Connecting the Failsafe Alarm Relay	12
2.1.4 Installing the Fan Tray Cables	12
2.1.5 Installing the Mounting Brackets	14
2.1.6 Installing the EMI Gaskets	15
2.1.7 Assembling the MX5000 and MX5000RE	16
2.1.8 Installing the Fan Tray	18
2.1.9 Installing the Patch Panels	19
2.1.10 Connecting the Network Cables	21
2.1.11 Installing the Front Panel	21
2.1.12 Mounting the MX5000RE	22
2.2 Connecting Power	23
2.2.1 Installing/Removing Power Supplies	24
2.2.1.1 Installing a Power Supply	24
2.2.1.2 Removing a Power Supply	25
2.2.2 Connecting Power to the Enclosure	26
2.3 Connecting to the Device	26
2.4 Cabling Recommendations	28

2.4.1 Protection On Twisted-Pair Data Ports	28
2.4.2 Gigabit Ethernet 1000Base-TX Cabling Recommendations	28

Chapter 3

Communication Ports	31
3.1 Serial Ports	32
3.2 Switch Ports	33
3.3 Copper Ethernet Ports	34
3.4 Fiber Optic Ethernet Ports	36
3.5 Installing/Removing Modules	36
3.5.1 Installing a Module	36
3.5.2 Removing a Module	37
3.6 Connecting Multiple RS485 Devices	38

Chapter 4

Technical Specifications	41
4.1 Power Supply Specifications	41
4.2 Failsafe Relay Specifications	41
4.3 Copper Ethernet Port Specifications	42
4.4 Fiber Optic Ethernet Port Specifications	42
4.4.1 Fast Ethernet (100 Mbps) Optical Specifications	42
4.4.2 Gigabit Ethernet (1 Gbps) Optical Specifications	43
4.5 Serial Port Specifications	43
4.6 Operating Environment	44
4.7 Mechanical Specifications	44

Chapter 5

Dimension Drawings	45
---------------------------------	-----------

Chapter 6

Certification	47
6.1 Approvals	47
6.1.1 TÜV	47
6.1.2 European Commission (EC)	47
6.1.3 FCC	48
6.1.4 FDA/CDRH	48
6.1.5 ISO	48
6.1.6 Industry Canada	49
6.1.7 Other Approvals	49
6.2 MIL-STD Ratings	49
6.3 EMC and Environmental Type Tests	49

Preface

This guide describes the RUGGEDCOM MX5000RE. It describes the major features of the device, installation, commissioning and important technical specifications.

It is intended for use by network technical support personnel who are responsible for the installation, commissioning and maintenance of the device. It is also recommended for use by network and system planners, system programmers, and line technicians.

Alerts

The following types of alerts are used when necessary to highlight important information.



DANGER!

DANGER alerts describe imminently hazardous situations that, if not avoided, will result in death or serious injury.



WARNING!

WARNING alerts describe hazardous situations that, if not avoided, may result in serious injury and/or equipment damage.



CAUTION!

CAUTION alerts describe hazardous situations that, if not avoided, may result in equipment damage.



IMPORTANT!

IMPORTANT alerts provide important information that should be known before performing a procedure or step, or using a feature.



NOTE

NOTE alerts provide additional information, such as facts, tips and details.

Related Documents

Other documents that may be of interest include:

- *ROX II User Guide for the MX5000RE*

Accessing Documentation

The latest user documentation for RUGGEDCOM MX5000RE v is available online at www.siemens.com/ruggedcom. To request or inquire about a user document, contact Siemens Customer Support.

Training

Siemens offers a wide range of educational services ranging from in-house training of standard courses on networking, Ethernet switches and routers, to on-site customized courses tailored to the customer's needs, experience and application.

Siemens' Educational Services team thrives on providing our customers with the essential practical skills to make sure users have the right knowledge and expertise to understand the various technologies associated with critical communications network infrastructure technologies.

Siemens' unique mix of IT/Telecommunications expertise combined with domain knowledge in the utility, transportation and industrial markets, allows Siemens to provide training specific to the customer's application.

For more information about training services and course availability, visit www.siemens.com/ruggedcom or contact a Siemens sales representative.


Customer Support

Customer support is available 24 hours, 7 days a week for all Siemens customers. For technical support or general information, contact Siemens Customer Support through any of the following methods:



Online

Visit <http://www.siemens.com/automation/support-request> to submit a Support Request (SR) or check on the status of an existing SR.



Telephone

Call a local hotline center to submit a Support Request (SR). To locate a local hotline center, visit <http://www.automation.siemens.com/mcms/aspa-db/en/automation-technology/Pages/default.aspx>.



Mobile App

Install the Industry Online Support app by Siemens AG on any Android, Apple iOS or Windows mobile device and be able to:

- Access Siemens' extensive library of support documentation, including FAQs and manuals
- Submit SRs or check on the status of an existing SR
- Contact a local Siemens representative from Sales, Technical Support, Training, etc.
- Ask questions or share knowledge with fellow Siemens customers and the support community



Introduction

The RUGGEDCOM MX5000RE is a MIL-STD, high-port density routing and switching platform, designed to operate in the most demanding environments. The MX5000RE can withstand high levels of electromagnetic interference, radio frequency interference, and a wide temperature range of -40 to 85 °C (-40 to 185 °F). The MX5000RE is designed to meet the challenging climatic and environmental demands found in utility, industrial, and military network applications.

The MX5000RE's superior hardware design, coupled with the embedded RUGGEDCOM MX5000RE operating system, provides improved system reliability for the most demanding network applications. The cyber security and networking features make it ideally suited for creating secure Ethernet networks for mission critical, real-time, control applications.

The MX5000RE is a scalable, modular platform providing the ability to change the configuration as the network grows and needs change.

The enclosure is a tough, welded aluminum, hard-mount enclosure built to house Siemens networking products and provide MIL-STD ratings for shock, vibration, emissions, immunity, temperature, and humidity. Ten external patch panels with up to 64 MIL grade round connectors provide tremendous flexibility and allow the enclosure to be employed in many diverse applications. A variety of patch panel cable assemblies allow convenient and simple mapping from internal electronics to the outside world.

The enclosure is rated for IP65 ingress protection, meaning that it is dust tight and can withstand water from a nozzle in any direction. Constructed with aluminum extrusions with fins on both sides and combined with high reliability internal circulation fans, the enclosure optimizes heat transfer without the exchange of outside air and improves the MTBF for the enclosed electronics.

The MX5000 installed with the enclosure provides an extremely flexible package with MIL-STD approvals, continuing Siemens's tradition of pioneering advanced networking solutions specifically for the harsh environments found in military applications.

The following sections provide more information about the MX5000RE:

- [Section 1.1, "Feature Highlights"](#)
- [Section 1.2, "Description"](#)
- [Section 1.3, "Patch Panels"](#)

Section 1.1

Feature Highlights

Ethernet Ports

- Up to 48 copper ports
- Up to 48 100Base-FX optical ports
- Up to 2 Gigabit Ethernet ports
- Long-haul optics allow distances up to 90 km (56 mi)
- Multiple connector types: ST, MTRJ, LC, SC

Reliability in Harsh Environments

- Immunity to EMI and high voltage electrical transients
- Zero-Packet-Loss Technology
- -40 to 85 °C (-40 to 185 °F) operating temperature (no fans within chassis or modules)
- Conformal coated printed circuit boards (optional)

Modularity

- Up to 6 slots for line modules
- Up to 48 10/100Base-TX or 48 100Base-FX ports

Universal Power Supply Options

- Fully integrated, dual-redundant (optional) power supplies
- Universal high voltage ranges: 88-300 VDC or 85-264 VAC
- Terminal blocks for reliable maintenance-free connections
- CSA/UL 60950-1 safety approved to 85 °C (185 °F)

Enclosure Features

- Welded 6061-T4 aluminum extrusion construction
- Welded 6061-T6 aluminum mounting brackets for MIL901D hard mounting
- Configurable patch panel allows up to 64 MIL grade circular connectors for both copper and fiber media
- Integrated cable management for strain relief
- Removable front panel with EMI glass for service and maintenance
- Hard-mounted brackets fit standard 48 cm (19 in) rack mount equipment
- Dual internal MIL grade high reliability fans minimize internal temperature gradient with no outside air exchange
- IEC 60529 IP65 rated; dust tight, water jets

Section 1.2

Description

The MX5000RE features various ports, controls and indicator LEDs on individual modules and the front panel for connecting, configuring and troubleshooting the device.




Figure 1: RUGGEDCOM MX5000RE Modules

1. Control Module 2. Power Module 3. Line Module (Typical) 4. Alarm Indicator LED 5. Lamp Test/Alarm Cut-Off (LT/ACO) Button
6. Management Ethernet Port 7. Utility USB Port 8. RS232 Serial Console Port (DB9) 9. Failsafe Alarm Relay 10. Compact Flash Card Port
11. Power Module Indicator LEDs 12. Power Supply Terminal Block

When the MX5000RE is configured for *rack front* mounting, these ports, controls and LEDs are located on the front panel.




Figure 2: Front Panel

1. Power Module Indicator LEDs 2. Alarm Indicator LEDs 3. Utility USB Port 4. Management Ethernet Port 5. Lamp Test/Alarm Cut-Off (LT/ACO) Button 6. RS232 Serial Console Port (DB9)

Power Module Indicator LEDs

- Indicate the status of the power modules.
- I = The power supply is receiving power
 - O = The power supply is supplying power

Alarm Indicator LED	Indicates when an alarm condition exists. <ul style="list-style-type: none"> • Green = Alarms cleared/acknowledged • Red = Alarm
Lamp Test/Alarm Cut-Off (LT/ACO) Button	This button performs two functions: <ul style="list-style-type: none"> • Press and hold this button to test all indicator LEDs • Press and release this button to acknowledge an active alarm
Management Port	This 10/100Base-T Ethernet port is used for system management that is out-of-band from the switch fabric.
Utility USB Port	Use the USB port to upgrade the ROX II software or install files, such as configuration files and feature key files. For more information, refer to the <i>RUGGEDCOM ROX II User Guide</i> for the RUGGEDCOM MX5000RE.
Compact Flash Card Port	Houses the compact flash card, which contains active and backup installations of ROX II, along with the configuration database and other system data.
RS232 Serial Console Port	The serial console port is for interfacing directly with the device and accessing initial management functions. For information about connecting to the device via the serial console port, refer to Section 2.3, "Connecting to the Device" .
Failsafe Alarm Relay	Latches to default state when a power disruption or other alarm condition occurs. For more information, refer to: <ul style="list-style-type: none"> • Section 2.1.3, "Connecting the Failsafe Alarm Relay" • Section 4.2, "Failsafe Relay Specifications"
Power Supply Terminal Block	A pluggable terminal block. For more information, refer to: <ul style="list-style-type: none"> • Section 2.2, "Connecting Power" • Section 4.1, "Power Supply Specifications"

Section 1.3

Patch Panels

Every module slot in the MX5000 chassis is connected to a patch panel assembly in the enclosure. Patch panels are provided pre-assembled with the appropriate ports and wiring to make installation quick and simple.

The following maps the patch panels to their associated line module slot in the MX5000 chassis.




Figure 3: Patch Panels

Patch Panel	MX5000 Module Slot
A	LM1
B	LM2
C	LM3
D	CM
E	PM1
F	SM
G	PM2
H	LM4
I	LM5
J	LM6

2 Installing the Device

The following sections describe how to install the device, including mounting the device, connecting power, and connecting the device to the network.



DANGER!

Electrocution hazard – risk of serious personal injury and/or damage to equipment. Before performing any maintenance tasks, make sure all power to the device has been disconnected and wait approximately two minutes for any remaining energy to dissipate.



WARNING!

Burn hazard – risk of serious personal injury. Avoid contact with the surface of the unit. The metal surface may be hot due to the high allowable ambient temperature per specification.

Éviter tout contact avec la surface. La surface métallique peut être chaude à cause d'une température ambiante élevée selon les spécifications. S.V.P. se référer à la version française de ce guide pour les détails.



WARNING!

*Radiation hazard – risk of serious personal injury. This product contains a laser system and is classified as a **CLASS 1 LASER PRODUCT**. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.*



IMPORTANT!

This product contains no user-serviceable parts. Attempted service by unauthorized personnel shall render all warranties null and void.

Changes or modifications not expressly approved by Siemens Canada Ltd. could invalidate specifications, test results, and agency approvals, and void the user's authority to operate the equipment.



IMPORTANT!

*This product should be installed in a **restricted access location** where access can only be gained by authorized personnel who have been informed of the restrictions and any precautions that must be taken. Access must only be possible through the use of a tool, lock and key, or other means of security, and controlled by the authority responsible for the location.*

- [Section 2.1, “Assembling the MX5000RE”](#)
- [Section 2.3, “Connecting to the Device”](#)
- [Section 2.4, “Cabling Recommendations”](#)

Section 2.1

Assembling the MX5000RE

To assemble the MX5000 with the MX5000RE enclosure, do the following:



CAUTION!

Mechanical hazard – risk of damage to equipment. Do not apply vertical force to the handles on the modules. Damage to the handles may occur, which is not covered by warranty. Avoid resting the device on any flat surface where pressure is applied to the module handles.

1. Install the power supply patch cables. For more information, refer to [Section 2.1.1, “Installing the Power Supply Patch Cables”](#).
2. If necessary, install the MX5000 chassis ground connection. For more information, refer to [Section 2.1.2, “Installing the Chassis Ground Connection”](#).
3. Connect the failsafe relay and connect the patch cables. For more information, refer to [Section 2.1.3, “Connecting the Failsafe Alarm Relay”](#).
4. Install the fan tray cables. For more information, refer to [Section 2.1.4, “Installing the Fan Tray Cables”](#).
5. Install the mounting brackets. For more information, refer to [Section 2.1.5, “Installing the Mounting Brackets”](#).
6. Install the EMI gaskets. For more information, refer to [Section 2.1.6, “Installing the EMI Gaskets”](#).
7. Assemble the MX5000 with the enclosure. For more information, refer to [Section 2.1.7, “Assembling the MX5000 and MX5000RE”](#).
8. Install the fan tray. For more information, refer to [Section 2.1.8, “Installing the Fan Tray”](#).
9. Install the patch panels. For more information, refer to [Section 2.1.9, “Installing the Patch Panels”](#).
10. Connect network cables to the patch panels. For more information, refer to [Section 2.1.10, “Connecting the Network Cables”](#).
11. Install the front panel. For more information, refer to [Section 2.1.11, “Installing the Front Panel”](#).
12. Mount the MX5000RE. For more information, refer to [Section 2.1.12, “Mounting the MX5000RE”](#).

Section 2.1.1

Installing the Power Supply Patch Cables

To connect the power supply patch cables to the enclosure, do the following:

1. Remove the screws from the outer safety cover.




Figure 4: Power Supply Patch Cable Connections

1. #6-32×3/8" Pan Head Screw 2. Outer Safety Cover 3. Inner Safety Cover 4. Terminal Lug Screws 5. Terminal Ring Lug
6. Terminal Block 7. PS1 Cable Assembly 8. MX5000 9. PS2 Cable Assembly

2. Remove the outer safety cover and the inner safety cover from the MX5000.
3. Remove the three terminal lug screws from the terminal block.



DANGER!

Electrocution hazard – risk of death, serious personal injury and/or damage to the device. Make sure the supplied cover is always installed over high voltage screw-type terminal blocks.



CAUTION!

Electrical hazard – risk of damage to equipment. Do not connect AC power cables to a DC power supply terminal block. Damage to the power supply may occur.

4. Connect the live (+/L) lug from the PS1 cable assembly to the live terminal on the PS1 terminal block.




Figure 5: AC Terminal Block Wiring

1. Live Terminal 2. Ground Terminal 3. Neutral Terminal




Figure 6: DC Terminal Block Wiring

1. Live Terminal 2. Ground Terminal 3. Neutral Terminal

5. Connect the neutral (-/N) lug from the PS1 cable assembly to the neutral terminal on the PS1 terminal block.



IMPORTANT!

If the ground terminals are not connected to safety Earth, the chassis ground connection must be connected. For more information, refer to [Section 2.1.2, "Installing the Chassis Ground Connection"](#).

6. Connect the ground (GND) lug from the PS1 cable assembly to the ground terminal on the PS1 terminal block.
7. If necessary, repeat [Step 4](#) to [Step 6](#) to connect the PS2 cable assembly.

8. Install the inner and outer safety covers, making sure the cables pass through the openings in the sides of the covers.
9. Secure the inner and outer supply safety covers with the screws removed in [Step 1](#).

Section 2.1.2

Installing the Chassis Ground Connection

If the ground terminal on the power supply module(s) is not connected to safety Earth, a connection must be provided from the chassis ground terminal on the MX5000 chassis.



IMPORTANT!

*If the ground terminal on the power supply module(s) **is** connected to safety Earth, a connection from the chassis ground terminal is not required.*

1. Position the grounding cable and external tooth lock washer on the MX5000.




Figure 7: Chassis Ground Cable Assembly

1. External Tooth Lock Washer 2. #8-32×5/16" Pan Head Screw 3. Grounding Cable

2. Secure the grounding cable and external tooth lock washer to the MX5000 with one pan head screw. Torque the screw to 3.4 N·m (30 lbf·in).




NOTE
The other end of the grounding cable will be connected to the inside of the enclosure in later steps.

Section 2.1.3

Connecting the Failsafe Alarm Relay


The failsafe relay on the Control Module (CM) can be configured to latch based on alarm conditions. The NO (Normally Open) contact is closed when the unit is powered and there are no active alarms. If the device is not powered or if an active alarm is configured, the relay opens the NO contact and closes the NC (Normally Closed) contact.



Pin	Function
NC	Normally Closed
Common	Ground
NO	Normally Open

Figure 8: Failsafe Alarm Relay Wiring
1. Normally Open 2. Common (Ground) 3. Normally Closed

The failsafe relay terminal is connected to the patch panel for the CM using the cable assembly provided. The connector is an Amphenol MIL-DTL 38999 size 13, code A. The following is the pin-out for the connector:



Pin	Description
A	COM (Common)
B	NO (Normally Open)
C	NC (Normally Closed)
D	Spare

Figure 9: Failsafe Relay Alarm Panel Connector

Section 2.1.4

Installing the Fan Tray Cables

1. Apply Loctite® 222 to the threads of the fan tray cable connector threads.





Figure 10: Fan Tray Cable Connections

1. Fan Cables

2. Attach two fan cables to the terminals on the rear of the MX5000.
3. Using two cable ties, secure the fan cables and power cables to the cable tie base on the rear of the MX5000. Make sure the cable ties are snug and the cables are unable to slide freely.



4. After tightening the cable ties, trim and remove any excess length.

Section 2.1.5

Installing the Mounting Brackets

1. Position one of the mounting brackets on one side of the MX5000.




Figure 12: Mounting Brackets

1. Mounting Bracket 2. #10-32×1/2" Flat Head Hex Socket Screw

- 2. Secure the mounting bracket with 20 flat head hex socket screws. Hand tighten each screw and make sure each screw head is flush with the surface of the mounting bracket.
- 3. Repeat [Step 1](#) and [Step 2](#) for the mounting bracket on the opposite side of the MX5000.

Section 2.1.6

Installing the EMI Gaskets

The material for the EMI (Electro-Magnetic Interference) gaskets is provided in two lengths for the two different sizes of patch panel openings in the MX5000:

EMI Gasket Material Length	Patch Panel Opening
19.5"	D, E, F and G
35.5"	A, B, C, H, J and K

To install the EMI gaskets, do the following:


- 1. Make sure the groove surrounding each panel opening is free of dust, dirt or liquid.
- 2. Inspect each gasket for signs of twisting, cracking, wear or damage. If the gaskets need to be replaced, cut and discard the them.



IMPORTANT!

- Do not stretch the gasket material. Stretching the gasket material will degrade performance. If gasket material is inadvertently stretched, remove it from the patch panel groove and allow it to sit for 8 hours before attempting to install it again. The material will return to its original length.
- Do not cut the gasket to length before assembly.

3. Starting at the overlapping section of a patch panel groove, gently press a length of gasket material into the groove. Work around the groove until the gasket is seated all around the opening and in the overlapping section. Make sure the gasket material is loose and is not stretched during installation.



4. Trim the gasket material to length.
5. Repeat [Step 3](#) and [Step 4](#) for each patch panel opening.

Section 2.1.7

Assembling the MX5000 and MX5000RE

To install the MX5000 in the MX5000RE, do the following:

1. Position the MX5000RE with the front opening facing up.




Figure 14: MX5000 and MX5000RE Assembly

1. #10-32×1" Screw 2. #10 Split Lockwasher 3. #10 Flat Washers 4. Grounding Cable 5. #10 Exterior Tooth Lockwasher
6. #10-32 Hex Nut 7. Power Supply Cable Assemblies 8. #6-32×3/8" SS304 Truss Head Philips Drive Screw 9. Inside
Grounding Stud



WARNING!

Crushing hazard – risk of serious injury or damage to equipment. Make sure the device is properly supported at all times. It is highly recommended to employ the assistance of another technician.

2. Have an assistant hold the attached cables and patch panel clear of the MX5000RE sides.
3. Hold the MX5000 by both mount bracket handles and lower it into the MX5000RE.
4. Lower the MX5000 unit until the mount bracket flanges are supporting the unit on the inner mount bracket surfaces. If the MX5000 does not lower far enough, make sure the support pins on the back of the mount brackets are properly aligned with the alignment holes inside the MX5000RE.
5. Secure the MX5000 to the MX5000RE using 18 screws, flat washers and split lockwashers. Make sure each screw is assembled with two flat washers, one split lockwasher and then the screw.
6. Place one exterior tooth lockwasher on the inside grounding stud found on the right side of the MX5000RE.
7. Attach the free end of the grounding cable to the inside grounding stud using two hex nuts.

8. Carefully pass the PS1 power supply cable assembly through opening E on the bottom of the MX5000RE.
9. Carefully pass the PS2 power supply cable assembly through opening G on the bottom of the MX5000RE.



NOTE

When aligning the patch panels, the inside grounding stud should be toward the back of the MX5000RE.

10. Apply Loctite® 242 to four SS304 truss head philips drive screws.
11. Secure both patch panels to the MX5000RE with four SS304 truss head philips drive screws.

Section 2.1.8

Installing the Fan Tray

To install the fan tray, do the following:

1. Position the fan tray the DB25 connectors facing forward when the fan tray is in the MX5000RE.




Figure 15: Fan Tray Installation

1. #8-32×5/16" Pan Head Screw 2. Fan Tray

2. Align the fan tray with the pins on the bottom of the internal mounting brackets inside the MX5000RE.
3. Slide the fan tray onto the locating pins until the fan tray mount brackets touch the MX5000RE inner mount brackets.
4. Secure the fan tray using six (6) screws. Use Loctite® 242 on all screws.
5. Take the free ends of the fan control cables and straighten the cables side by side.

6. Take the right side fan control cable and thread it through the three (3) loops on the left side of the fan tray.
7. Connect the fan control cable to the left side DB25 connector.
8. Repeat [Step 6](#) and [Step 7](#) using the left side fan control cable.
9. Apply Loctite® 222 on the DB25 plug screws. Tighten the DB25 connector screws moderately.




Figure 16: Fan Tray Cable Clips

1. Cable Clip

10. Secure the cables using two (2) cable ties through the slots on the outermost cable clips on the fan tray. Make sure the cables are held snug and are unable to slide freely.
11. After tightening the cable ties, trim and remove any excess length.

Section 2.1.9

Installing the Patch Panels

To install a patch panel, do the following:



NOTE

The following procedure also applies for blank patch panels.

1. From the bottom of the enclosure, feed the patch panel cables through the appropriate opening. For more information about which patch panels correspond to which openings, refer to [Section 1.3, "Patch Panels"](#).




Figure 17: Patch Panel Installation

1. #6-32×5/8" SS304 Truss Head Philips Drive Screw 2. Patch Panel

2. Align the patch panel with the screw holes surrounding the patch panel opening.
3. Apply Loctite® 242 to each screw.
4. Secure the patch panel to the enclosure with eight (8) screws for large panels, or four (4) for small panels. Hand-tighten the screws evenly in a cross pattern. There should be no visible gap between the patch panel and the enclosure's bottom plate when properly tightened. Pay careful attention to avoid damaging the cables and gaskets.

Section 2.1.10

Connecting the Network Cables

To connect network cables to the patch panels, do the following for each patch panel:

» Connecting Micro-D Cables

1. Connect each cable in the patch panel bundle to the appropriate port. Make sure the cable and port have identical numbers.
2. Secure the bundled cables to an available cable tie base using one (1) cable tie. Tighten the cable tie until the bundled cables are held securely.
3. Install additional cable ties where necessary.

» Connecting Ethernet Cables

1. Carefully remove the dust caps from one connector at a time.
2. Insert the uncapped connector into the appropriate transceiver on the MX5000. Make sure the cable and port have the same number, and the transmit and receive fibers are plugged in to the correct side of the transceiver.
3. Repeat [Step 1](#) and [Step 2](#) for all remaining fiber cables.
4. Secure all fiber cables with the provided Velcro® straps. Wrap the Velcro® cable strap around the fiber cables tightly, making sure the fiber cables are held securely.

Section 2.1.11

Installing the Front Panel

To install the front panel for the MX5000RE, do the following:

1. Position the MX5000RE with the front opening facing up.




Figure 18: Front Panel Installation



WARNING!

Crushing hazard – risk of serious injury or damage to equipment. Make sure the front panel is properly supported at all times. It is highly recommended to employ the assistance of another technician.

2. Position the front panel over the MX5000RE opening, aligning the panel with the two (2) locating pins on the front face.
3. Secure the front panel with 24 screws. Hand-tighten the screws evenly in a cross pattern.

Section 2.1.12

Mounting the MX5000RE

To mount the fully assembled MX5000RE to its final mounting surface, do the following:

1. Make sure the mounting surface is flat within a tolerance of 0.254 mm (0.010 in).
2. Position the enclosure with the lifting ring facing up.




Figure 19: Mounting the MX5000RE

1. Screw



WARNING!

Crushing hazard – risk of serious injury or damage to equipment. Make sure the front panel is properly supported at all times. It is highly recommended to employ the assistance of another technician.

3. Secure the MX5000RE to a wall or mounting bracket using screws. Torque each screw evenly to 61 N·m (45 lbf-ft) in a cross pattern.

Section 2.2

Connecting Power

The MX5000RE supports dual redundant AC and/or DC power supplies that can be installed in any combination. The use of two power modules is recommended to provide redundancy and load balancing.

The MX5000 is equipped with a screw-type terminal block, which provides power to both power supplies. The terminal block is installed using Philips screws and compression plates, allowing either bare wire connections or crimped terminal lugs. Use #6 size ring lugs for secure, reliable connections under severe shock or vibration.



IMPORTANT!

- *In an AC/DC power arrangement, the placement of the AC and DC power supplies is not slot-dependent. Either power module slot can be used for AC or DC power.*
- *For maximum redundancy in a dual power supply configuration, use two independent power sources.*
- *Use only #16 gage copper wiring when connecting terminal blocks.*
- *For 125/230 VAC rated equipment, an appropriately rated AC circuit breaker must be installed.*
- *For 125/250 VDC rated equipment, an appropriately rated DC circuit breaker must be installed.*
- *It is recommended to provide a separate circuit breaker for each power supply module.*
- *Equipment must be installed according to applicable local wiring codes and standards.*

The following sections describe how to connect power to the device:

- [Section 2.2.1, “Installing/Removing Power Supplies”](#)
- [Section 2.2.2, “Connecting Power to the Enclosure”](#)

Section 2.2.1

Installing/Removing Power Supplies

The MX5000 supports dual redundant AC and/or DC power supplies that can be installed in any combination. Slots for the removable power modules are located on the rear panel of the device.




Figure 20: Power Module Slots

1. Slot PS1 2. Slot PS2



DANGER!

Electrocution hazard – risk of serious personal injury or death. The device may have two power supplies equipped, which may be connected to separate power sources. Make sure all power sources are isolated before servicing the power supplies.

The following sections describe how to install, remove and connect the power supplies:

- [Section 2.2.1.1, “Installing a Power Supply”](#)
- [Section 2.2.1.2, “Removing a Power Supply”](#)

Section 2.2.1.1

Installing a Power Supply

To install a power supply, do the following:




NOTE

The power supplies are hot swappable. It is not necessary to disconnect power to the device before installing or removing a power supply.

1. Remove the blank power module assembly or, if equipped, the currently installed power supply. For information about removing a power supply, refer to [Section 2.2.1.2, “Removing a Power Supply”](#).

2. Insert the power supply into the empty slot. When power is supplied to the device, the top and bottom LEDs on the power supply should be green, indicating that power is being received and supplied to the device.



3. Hand-tighten the screws to secure the power supply.

Section 2.2.1.2

Removing a Power Supply

To remove a power supply, do the following:



NOTE

The power supplies are hot swappable. It is not necessary to disconnect power to the device before Removing or removing a power supply.

1. Remove the screws that secure the power supply.
2. Pull the power supply from the chassis.




Figure 22: Removing a Power Supply

1. Screws 2. Power Supply 3. Chassis

3. Install the blank power module assembly into the empty slot to prevent the ingress of dust and dirt.

Section 2.2.2

Connecting Power to the Enclosure

To complete the power circuit, connect an external power supply to the PS1 and/or PS2 patch panels using male Amphenol MIL-DTL 389999 size 13, code N connectors.




Figure 23: Power Supply Panel Connector

Pin	Description
A	PS Live/+
B	Spare
C	PS Neutral/-
D	Spare

Section 2.3

Connecting to the Device

The following describes the various methods for accessing the ROX II console and Web interfaces on the device. For more detailed instructions, refer to the *ROX II User Guide* for the RX5000.

Serial Console and Management Ports

Connect a PC or terminal directly to the serial console or management ports to access the boot-time control and ROX II interfaces. The serial console port provides access to ROX II's console interface, while the management port provides access to ROX II's console and Web interfaces.



IMPORTANT!
The serial console and management (MGMT) ports are intended to be used only as temporary connections during initial configuration or troubleshooting.

The serial console port implements RS232 DCE (Data Communication Equipment) on a DB9 connector. The following is the pin-out for the port:




Figure 24: Serial DB9 Console Port

Pin	Name	Description
1	DCD	Data Carrier Detect
2	RX	Receive Data
3	TX	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Signal Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear To Send
9	Reserved (Do Not Connect)	

The management port is a 10/100Base-TX copper Ethernet port with an RJ45 connector. The following is the pin-out for the management port:




Figure 25: RJ45 Management Port

Pin	Name	Description
1	TX+	Transmit Data+
2	TX-	Transmit Data-
3	RX+	Receive Data+
4	Reserved (Do Not Connect)	
5	Reserved (Do Not Connect)	
6	RX-	Receive Data-
7	Reserved (Do Not Connect)	
8	Reserved (Do Not Connect)	

Communication Ports

Connect any of the available Ethernet ports on the device to a management switch and access the ROX II console and Web interfaces via the device's IP address. The factory default IP address for the RUGGEDCOM MX5000RE is <https://192.168.0.2>.

For more information about available ports, refer to [Chapter 3, Communication Ports](#).

Section 2.4

Cabling Recommendations

Before connecting the device, be aware of the recommendations and considerations outlined in the following sections:

- [Section 2.4.1, “Protection On Twisted-Pair Data Ports”](#)
- [Section 2.4.2, “Gigabit Ethernet 1000Base-TX Cabling Recommendations”](#)

Section 2.4.1

Protection On Twisted-Pair Data Ports

All copper Ethernet ports on RUGGEDCOM products include transient suppression circuitry to protect against damage from electrical transients and conform with IEC 61850-3 and IEEE 1613 Class 1 standards. This means that during a transient electrical event, communications errors or interruptions may occur, but recovery is automatic.

Siemens also does not recommend using copper Ethernet ports to interface with devices in the field across distances that could produce high levels of ground potential rise (i.e. greater than 2500 V), during line-to-ground fault conditions.

Section 2.4.2

Gigabit Ethernet 1000Base-TX Cabling Recommendations

The IEEE 802.3ab Gigabit Ethernet standard defines 1000 Mbit/s Ethernet communications over distances of up to 100 m (328 ft) using all 4 pairs in category 5 (or higher) balanced, unshielded twisted-pair cabling. For wiring guidelines, system designers and integrators should refer to the Telecommunications Industry Association (TIA) TIA/EIA-568-A wiring standard that characterizes minimum cabling performance specifications required for proper Gigabit Ethernet operation. For reliable, error-free data communication, new and pre-existing communication paths should be verified for TIA/EIA-568-A compliance.

The following table summarizes the relevant cabling standards:

Cabling Category	1000Base-TX Compliant	Required Action
< 5	No	New wiring infrastructure required.
5	Yes	Verify TIA/EIA-568-A compliance.
5e	Yes	No action required. New installations should be designed with Category 5e or higher.
6	Yes	No action required.
> 6	Yes	Connector and wiring standards to be determined.

Follow these recommendations for copper data cabling in high electrical noise environments:

- Data cable lengths should be as short as possible, preferably 3 m (10 ft) in length. Copper data cables should not be used for inter-building communications.
- Power and data cables should not be run in parallel for long distances, and should be installed in separate conduits. Power and data cables should intersect at 90° angles when necessary to reduce inductive coupling.

- Shielded/screened cabling can be used when required. Care should be taken to avoid the creation of ground loops with shielded cabling.

3

Communication Ports

The MX5000 can be equipped with various types of communication ports to enhance its abilities and performance. Each set of communication ports is part of a field replaceable module that makes switching ports fast and easy.

Use the ROX II software to determine which ports are equipped on the device. For more information, refer to the *ROX II User Guide* for the RX5000.

Each type of module has a specific location in the MX5000 chassis.




Figure 26: Module Assignment

1. Ethernet Module Slot (LM1) 2. Ethernet Module Slot (LM2) 3. Ethernet Module Slot (LM3) 4. Switch Module (SM) 5. Ethernet Module Slot (LM4) 6. Ethernet Module Slot (LM5) 7. Ethernet Module Slot (LM6)

Slot Type	Description
SM	The <i>Switch Module</i> contains the chassis-wide Ethernet switch fabric that interconnects Ethernet ports on all installed line modules.
LM1 through LM6	One to six Ethernet Line Modules can be installed in the MX5000RE.



CAUTION!
Mechanical hazard – risk of damage to equipment. Do not apply vertical force to the handles on the modules. Damage to the handles may occur, which is not covered by warranty. Avoid resting the device on any flat surface where pressure is applied to the module handles.



IMPORTANT!
Use one of the available 88 Gigabit Ethernet switch modules when any 4-port Gigabit Ethernet line module is installed. When a 4-port Gigabit Ethernet line module is used with an 8 Gigabit Ethernet switch module, only the first port on the line module will be enabled.

**IMPORTANT!**

Use one of the available 88 Gigabit Ethernet switch modules when a 16-port 100TX copper line module is installed. Using an 8 Gigabit Ethernet switch module will cause an over-subscription of packets, resulting in random packet loss if the line module traffic exceeds 1 Gbps.

The following sections describe the available modules and how to install/remove them:

- [Section 3.1, “Serial Ports”](#)
- [Section 3.2, “Switch Ports”](#)
- [Section 3.3, “Copper Ethernet Ports”](#)
- [Section 3.4, “Fiber Optic Ethernet Ports”](#)
- [Section 3.5, “Installing/Removing Modules”](#)
- [Section 3.6, “Connecting Multiple RS485 Devices”](#)

Section 3.1

Serial Ports

The MX5000RE supports DB9 serial ports, which can be run in RS232, RS485 or RS422 mode.

**NOTE**

On power-up, all serial ports default to RS485 mode. Each port can be individually set to RS232, RS485 or RS422 mode through ROX II. For more information, refer to the ROX II User Guide for the MX5000RE.

>> LEDs

All serial ports feature an LED that indicates the current state of the port.

State	Description
Green	Link activity detected
Off	No link detected

>> Pin-Out Description

The following are the pin-outs for the DB9 connectors:




Figure 27: DB9 Serial Port

Pin	Function		
	RS232 Mode	RS422 Mode	RS485 Mode
1		RX-	
2	RX	TX+	TX+/RX+
3	TX	RX+	
4	IRIG_B_Out		
5	COM (Isolated GND)		
6	COM (Isolated GND)		
7		TX-	TX-/RX-
8			
9	COM (Isolated GND)		
Body	Chassis GND ^a		
Screws	Chassis GND ^a		

^a Connected internally.

>> Connecting to RS485 Devices

For information about how to connect devices configured to run in RS485 mode, refer to [Section 3.6, “Connecting Multiple RS485 Devices”](#).

>> Specifications

For specifications on serial ports, refer to [Section 4.5, “Serial Port Specifications”](#).

Section 3.2

Switch Ports

The MX5000RE supports a single Layer 2 or Layer 3 switch module that can operate at 8 or 88 Gbps. The switch module supports either RJ45, LC (Lucent Connector) or SC (Standard or Subscriber Connector) connectors.

>> Pin-Out Description

The following are the pin-out descriptions for the RJ45, LC and SC connectors:




Figure 28: RJ45 Ethernet Port Pin Configuration

Pin	Name		Description
	10/100Base-TX	1000Base-TX	
1	RX+	BI_DB+	Receive Data+ or Bi-Directional
2	RX-	BI_DB-	Receive Data- or Bi-Directional

Pin	Name		Description
	10/100Base-TX	1000Base-TX	
3	TX+	BI_DA+	Transmit Data+ or Bi-Directional
4	Reserved (Do Not Connect)		
5	Reserved (Do Not Connect)		
6	TX-	BI_DA-	Transmit Data- or Bi-Directional
7	Reserved (Do Not Connect)		
8	Reserved (Do Not Connect)		




Figure 29: SC Port

1. Tx Connector 2. Rx Connector




Figure 30: LC Port

1. Tx Connector 2. Rx Connector

>> Specifications

For specifications on the available fiber optic Ethernet ports, refer to [Section 4.3, “Copper Ethernet Port Specifications”](#) or [Section 4.4, “Fiber Optic Ethernet Port Specifications”](#).

Section 3.3

Copper Ethernet Ports

The MX5000RE supports several 10/100/1000Base-TX Ethernet ports that allow connection to standard Category 5 (CAT-5) unshielded twisted-pair (UTP) cables with either RJ45 or Micro-D male connectors. The RJ45 and Micro-D connectors are directly connected to the chassis ground on the device.



WARNING!

Electric shock hazard – risk of serious personal injury and/or equipment interference. If shielded cables are used, make sure the shielded cables do not form a ground loop via the shield wire and the RJ45 receptacles at either end. Ground loops can cause excessive noise and interference, but more importantly, create a potential shock hazard that can result in serious injury.

>> LEDs

Each RJ45 port features a **Speed** and **Link** LED that indicates the state of the port.

LED	State	Description
Speed	Yellow	The port is operating at maximum speed (100 or 1000 Mbps)

LED	State	Description
Link	Off	The port is not operating at maximum speed
	Yellow (Solid)	Link established
	Yellow (Blinking)	Link activity
	Off	No link detected

» Pin-Out Description

The following are the pin-out descriptions for the RJ45 and Micro-D connectors:




Figure 31: RJ45 Ethernet Port Pin Configuration

Pin	Name		Description
	10/100Base-TX	1000Base-TX	
1	RX+	BI_DB+	Receive Data+ or Bi-Directional
2	RX-	BI_DB-	Receive Data- or Bi-Directional
3	TX+	BI_DA+	Transmit Data+ or Bi-Directional
4	Reserved (Do Not Connect)		
5	Reserved (Do Not Connect)		
6	TX-	BI_DA-	Transmit Data- or Bi-Directional
7	Reserved (Do Not Connect)		
8	Reserved (Do Not Connect)		




Figure 32: Micro-D 10/100Base-TX Port Pin Configuration

Pin	10/100Base-TX	1000Base-TX
1	TX+	B+
2	Reserved (Do Not Connect)	D+
3	Reserved (Do Not Connect)	
4	Reserved (Do Not Connect)	C+
5	RX+	A+
6	TX-	B-
7	Reserved (Do Not Connect)	D-
8	Reserved (Do Not Connect)	C-
9	RX-	A-

» Specifications

For specifications on the available copper Ethernet ports, refer to [Section 4.3, “Copper Ethernet Port Specifications”](#).

Section 3.4

Fiber Optic Ethernet Ports

Fiber optic Ethernet ports are available with either MTRJ (Mechanical Transfer Registered Jack), LC (Lucent Connector), SC (Standard or Subscriber Connector) or ST (Straight Tip) connectors. Make sure the Transmit (Tx) and Receive (Rx) connections of each port are properly connected and matched to establish a proper link.




Figure 33: MTRJ Port

1. Tx Connector 2. Rx Connector




Figure 34: LC Port

1. Tx Connector 2. Rx Connector




Figure 35: SC Port

1. Tx Connector 2. Rx Connector




Figure 36: ST Port

1. Tx Connector 2. Rx Connector

For specifications on the available fiber optic Ethernet ports, refer to [Section 4.4, “Fiber Optic Ethernet Port Specifications”](#).

Section 3.5

Installing/Removing Modules

The following sections describe how to install and remove modules:

- [Section 3.5.1, “Installing a Module”](#)
- [Section 3.5.2, “Removing a Module”](#)

Section 3.5.1

Installing a Module

Upon installing a new module in the device, all the features associated to the module are available in the operating system. For more information, refer to the *ROX II User Guide* for the RX5000.

To install a module, do the following:

1. Make sure power to the device has been disconnected and wait approximately two minutes for any remaining energy to dissipate.
2. If the device is installed in a rack, remove it from the rack.
3. Remove the current module from the slot. For more information, refer to [Section 3.5.2, “Removing a Module”](#).
4. Insert the new module into the slot.




Figure 37: Installing a Module

1. Chassis 2. Module 3. Screw

5. Tighten the screws to secure the module.
6. If necessary, install the device in the rack.
7. Connect power to the device.

Section 3.5.2

Removing a Module

Once a module is removed, all the features associated with the module are hidden or disabled in the operating system.

To remove a module, do the following:

1. Make sure power to the device has been disconnected and wait approximately two minutes for any remaining energy to dissipate.
2. If the device is installed in a rack, remove it from the rack.
3. Loosen the screws that secure the module.
4. Pull the module from the chassis to disconnect it.




Figure 38: Removing a Module

1. Chassis 2. Module 3. Screw

5. Install a new module or a blank module (to prevent the ingress of dust and dirt). For more information, refer to [Section 3.5.1, “Installing a Module”](#).
6. If necessary, install the device in the rack.
7. Connect power to the device.

Section 3.6

Connecting Multiple RS485 Devices

Each RS485 port can communicate with multiple RS485 devices by wiring devices together in sequence over a single twisted pair with transmit and receive signals on the same two wires (half duplex). For reliable, continuous communication, adhere to the following guidelines:

- To minimize the effects of ambient electrical noise, use shielded cabling.
- The correct polarity must be observed throughout a single sequence or ring.
- The number of devices wired should not exceed 32, and total distance should be less than 1219 m (4000 ft) at 100 kbps.
- The Common terminals should be connected to the common wire inside the shield.
- The shield should be connected to earth ground at a single point to avoid loop currents.
- The twisted pair should be terminated at each end of the chain.

The following shows the recommended RS485 wiring.




Figure 39: Recommended RS485 Wiring

1. MX5000RE Device 2. Common (Isolated Ground) 3. Negative 4. Positive 5. Shield to Earth (Connected At a Single Point)
6. RS485 Devices (32 Total)

4 Technical Specifications

The following sections provide important technical specifications related to the device and available modules:

- [Section 4.1, “Power Supply Specifications”](#)
- [Section 4.2, “Failsafe Relay Specifications”](#)
- [Section 4.3, “Copper Ethernet Port Specifications”](#)
- [Section 4.4, “Fiber Optic Ethernet Port Specifications”](#)
- [Section 4.5, “Serial Port Specifications”](#)
- [Section 4.6, “Operating Environment”](#)
- [Section 4.7, “Mechanical Specifications”](#)

Section 4.1

Power Supply Specifications

Power Supply Type	Input Range		Internal Fuse Rating	Max. Power Consumption ^a
	Min	Max		
HI (125/250 VDC) ^b	88 VDC	300 VDC	6.3 A, 250 V(T) ^c	84 W ^d
HI (110/230 VAC) ^b	85 VAC	264 VAC		

^a Power consumption varies based on the device configuration. Each 10/100Base-Tx port consumes roughly 1 W less than a fiber optic port.

^b The HI power supply is the same power supply for both AC and DC.

^c (T) denotes time-delay fuse. Internal fuse is not user-replaceable.

^d Rating at 85 °C (185 °F) ambient temperature at worst-case load.

Section 4.2

Failsafe Relay Specifications

Maximum Switching Voltage	Rated Switching Current	Isolation
30 VDC	2 A, 60 W	1500 V _{rms} for 1 minute
125 VDC	0.24 A, 30 W	
125 VAC	0.5 A, 62.5 W	
220 VDC	0.24 A, 60 W	
250 VAC	0.25 A, 62.5 W	

Section 4.3

Copper Ethernet Port Specifications

The following details the specifications for copper Ethernet ports that can be ordered with the MX5000RE.

Speed ^e	Connector	Duplex ^e	Cable Type ^f	Wiring Standard ^g	Maximum Distance ^h	Isolation ⁱ
10/100Base-TX	RJ-45	FDX/HDX	> CAT 5	TIA/EIA T568A/B	100 m (328 ft)	1.5 kV
10/100Base-TX	Micro-D	FDX/HDX	> CAT 5	TIA/EIA T568A/B	100 m (328 ft)	1.5 kV
10/100Base-TX	Micro-D	FDX/HDX	> CAT 5	TIA/EIA T568A/B	100 m (328 ft)	1.5 kV

^e Auto-negotiating.

^f Shielded or unshielded.

^g Auto-crossover and auto-polarity.

^h Typical distance. Dependent on the number of connectors and splices.

ⁱ RMS 1 minute.

Section 4.4

Fiber Optic Ethernet Port Specifications

The following sections detail fiber optic specifications for ports that can be equipped on the MX5000RE. The user determines the type of optics at the time of ordering, and can determine the ports installed on a particular unit by reading the factory data file via the ROX II user interface. The specifications are organized by order code. Module order codes are contained within each unit when it is assembled and configured at the factory. For information about obtaining factory configuration data, refer to the *ROX II User Guide* for the RX5000.

- [Section 4.4.1, “Fast Ethernet \(100 Mbps\) Optical Specifications”](#)
- [Section 4.4.2, “Gigabit Ethernet \(1 Gbps\) Optical Specifications”](#)

Section 4.4.1

Fast Ethernet (100 Mbps) Optical Specifications

Mode	Connector Type	Cable Type (μm)	Tx λ (nm) ^j	Tx min. (dBm)	Tx max. (dBm)	Rx Sensitivity (dBm)	Rx Saturation (dBm)	Distance (km) ^j	Power Budget (dB)
MM	ST	62.5/125	1300	-19	-14	-31	-14	2	12
		50/125		-22.5					8.5
MM	SC	62.5/125	1300	-19	-14	-31	-14	2	12
		50/125		-22.5					8.5
MM	MTRJ	62.5/125	1300	-19	-14	-31	-14	2	12
		50/125		-22.5					8.5

Mode	Connector Type	Cable Type (μm)	Tx λ (nm) ^j	Tx min. (dBm)	Tx max. (dBm)	Rx Sensitivity (dBm)	Rx Saturation (dBm)	Distance (km) ^j	Power Budget (dB)
SM	ST	9/125	1310	-15	-8	-32	-3	20	17
SM	SC	9/125	1310	-15	-8	-31	-7	20	16
SM	LC	9/125	1310	-15	-8	-34	-7	20	19
SM	SC	9/125	1310	-5	0	-34	-3	50	29
SM	LC	9/125	1310	-5	0	-35	3	50	30
SM	SC	9/125	1310	0	5	-37	0	90	37
SM	LC	9/125	1310	0	5	-37	0	90	37
MM	LC	62.5/125	1300	-19	-14	-32	-14	2	13

^j Typical.

Section 4.4.2

Gigabit Ethernet (1 Gbps) Optical Specifications



NOTE

- Maximum segment length is greatly dependent on factors such as fiber quality, and the number of patches and splices. Consult a Siemens sales associate when determining maximum segment distances.
- All optical power numbers are listed as dBm averages.
- F51 transceivers are rated for -40 to 85 °C (-40 to 185 °F).

Mode	Connector Type	Cable Type (μm)	Tx λ (nm) ^k	Tx min. (dBm)	Tx max. (dBm)	Rx Sensitivity (dBm)	Rx Saturation (dBm)	Distance (km) ^k	Power Budget (dB)
MM	LC	50/125	850	-9	-2.5	-20	0	0.5	11
		62.5/125							
SM	SC	9/125	1310	-10	-3	-20	-3	10	10
SM	LC	9/125	1310	-9.5	-3	-21	-3	10	11.5
SM	SC	9/125	1310	-5	0	-20	-3	25	15
SM	LC	9/125	1310	-7	-3	-24	-3	25	17

^k Typical.

Section 4.5

Serial Port Specifications

Order Code	Baud Rate	Connector	Isolation
MS01	1200 to 230400 kbps	DB9	2.5 kV

Section 4.6

Operating Environment

Parameter	Range	Comments
Ambient Operating Temperature	-40 to 85 °C (-40 to 185 °F)	Measured from a 30 cm (12 in) radius surrounding the center of the enclosure.
Ambient Relative Humidity	5% to 95%	Non-condensing
Ambient Storage Temperature	-40 to 85 °C (-40 to 185 °F)	

Section 4.7

Mechanical Specifications

Parameter	Value
Dimensions	Refer to Chapter 5, Dimension Drawings .
Weight (MX5000)	14-16 kg (30-35 lbs)
Weight (Enclosure)	68 kg (150 lbs)
Ingress Protection (MX5000)	IP40
Ingress Protection (Enclosure)	IP65
Chassis Material (MX5000)	Aluminum
Chassis Material (Enclosure)	Aluminum alloy

5 Dimension Drawings



NOTE

All dimensions are in millimeters, unless otherwise stated.




Figure 40: Overall Dimensions

6 Certification

The RUGGEDCOM MX5000RE device has been thoroughly tested to guarantee its conformance with recognized standards and has received approval from recognized regulatory agencies.

- [Section 6.1, “Approvals”](#)
- [Section 6.3, “EMC and Environmental Type Tests”](#)

Section 6.1

Approvals

The following details the approvals issued for the RUGGEDCOM MX5000RE:

- [Section 6.1.1, “TÜV”](#)
- [Section 6.1.2, “European Commission \(EC\)”](#)
- [Section 6.1.3, “FCC”](#)
- [Section 6.1.4, “FDA/CDRH”](#)
- [Section 6.1.5, “ISO”](#)
- [Section 6.1.6, “Industry Canada”](#)
- [Section 6.1.7, “Other Approvals”](#)

Section 6.1.1

TÜV

This device is certified by TÜV to meet the requirements of the following standards:

- **CAN/CSA-C22.2 NO. 60950-1-07**
Information Technology Equipment – Safety – Part 1: General Requirements (Bi-National standard, with UL 60950-1)
- **UL 60950-1**
Information Technology Equipment – Safety – Part 1: General Requirements)

Section 6.1.2

European Commission (EC)

This device is declared by Siemens Canada Ltd. to comply with essential requirements and other relevant provisions of the following EC directives:

- **EN 60950-1**
Information Technology Equipment – Safety – Part 1: General Requirements

- **EN 61000-6-2**
Electromagnetic Compatibility (EMC) – Part 6-2: Generic Standards – Immunity for Industrial Environments
- **EN 60825-1**
Safety of Laser Products – Equipment Classification and Requirements
- **EN 55022**
Information Technology Equipment – Radio disturbance characteristics – Limits and methods of measurement
- **EN 50581**
Technical Documentation for the Assessment of Electrical and Electronic Products with Respect to the Restriction of Hazardous Substances

The device is marked with a CE marking and can be used throughout the European community.



A copy of the CE Declaration of Conformity is available from Siemens Canada Ltd.. For contact information, refer to [the section called “Contacting Siemens”](#).

Section 6.1.3

FCC

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference on his own expense.

Section 6.1.4

FDA/CDRH

This device meets the requirements of the following U.S. Food and Drug Administration (FDA) standard:

- Title 21 Code of Federal Regulations (CFR) – Chapter I – Sub-chapter J – Radiological Health

Section 6.1.5

ISO

This device was designed and manufactured using a certified ISO (International Organization for Standardization) quality program that adheres to the following standard:

- **ISO 9001:2008**
Quality management systems – Requirements

Section 6.1.6

Industry Canada

This device is declared by Siemens Canada Ltd. to meet the requirements of the following Industry Canada standard:

- CAN ICES-3 (A)/NMB-3 (A)

Section 6.1.7

Other Approvals

This device meets the requirements of the following additional standards:

- **IEEE 1613**
IEEE Standard Environmental and Testing Requirements for Communications Networking Devices in Electric Power Substations
- **IEC 61850-3**
Communications Networks and Systems for Power Utility Automation – Part 3: General Requirements
- **IEC 61000-6-2**
Electromagnetic Compatibility (EMC) – Part 6-2: Generic Standards – Immunity for Industrial Environments

Section 6.2

MIL-STD Ratings

Standard	Description	Comments
MIL-STD 901D	Shock (Hard-Mounted)	Approved
MIL-STD 461	EMI	Approved
DOD-STD 1399	Magnetic Field (DC Magnetic Exposure)	Approved
MIL-STD 1399 (Section 300B)	Electrical Power Interface Standards for Shipboard Systems	Approved

Section 6.3

EMC and Environmental Type Tests

The MX5000RE has passed the following EMC and environmental tests.

>> IEC 61850-3 EMC Type Tests

Test	Description		Test Levels	Severity Levels
IEC 61000-4-2	ESD	Enclosure Contact	+/- 8 kV	4
		Enclosure Air	+/- 15 kV	4

Test	Description		Test Levels	Severity Levels
IEC 61000-4-3	Radiated RFI	Enclosure Ports	20 V/m	Note ^a
IEC 61000-4-4	Burst (Fast Transient)	Signal ports	+/- 4 kV @ 2.5 kHz	Note ^a
		DC Power ports	+/- 4 kV	4
		AC Power ports	+/- 4 kV	4
		Earth ground ports	+/- 4 kV	4
IEC 61000-4-5	Surge	Signal ports	+/- 4 kV line-to-earth, +/- 2 kV line-to-line	4
		DC Power ports	+/- 2 kV line-to-earth, +/- 1 kV line-to-line	3
		AC Power ports	+/- 4 kV line-to-earth, +/- 2 kV line-to-line	4
IEC 61000-4-6	Induced (Conducted) RFI	Signal ports	10 V	3
		D.C Power ports	10V	3
		AC Power ports	10V	3
		Earth ground ports	10V	3
IEC 61000-4-8	Magnetic Field	Enclosure Ports	100 A/m	
			1000 A/m for 1 s	5
IEC 61000-4-29	Voltage Dips & Interrupts	DC Power ports	30% for 0.1 s, 60% for 0.1 s, 100% for 0.05 s	
		AC Power ports	30% for 1 period, 60% for 50 periods	
IEC 61000-4-11	Voltage Dips & Interrupts	AC Power ports	100% for 5 periods, 100% for 50 periods	
IEC 61000-4-12	Damped Oscillatory	Signal ports	2.5 kV common, 1 kV differential mode @1 MHz	3
		DC Power ports	2.5 kV common, 1 kV differential mode @1MHz	3
		AC Power ports	2.5 kV common, 1 kV differential mode @1MHz	3
IEC 61000-4-16	Mains Frequency Voltage	Signal ports	30 V Continuous, 300 V for 1 s	4
		DC Power ports	30 V Continuous, 300 V for 1 s	4
IEC 61000-4-17	Ripple on DC Power Supply	DC Power ports	10%	3
IEC 60255-5	Dielectric Strength	Signal ports	2 kV (Fail-Safe Relay output)	
		DC Power ports	2 kV	
		AC Power ports	2 kV	
	HV Impulse	Signal ports	5 kV (Fail-Safe Relay output)	
		DC Power ports	5 kV	
		AC Power ports	5 kV	

^a Siemens-specified severity levels

>> IEEE 1613 EMC Type Tests



NOTE

The MX5000RE meets Class 2 requirements for an all-fiber configuration and Class 1 requirements for copper ports.

Description		Test Levels
ESD	Enclosure Contact	+/-2 kV, +/-4 kV, +/- 8 kV
	Enclosure Air	+/-4 kV, +/-8 kV, +/-15 kV
Radiated RFI	Enclosure ports	35 V/m
Fast Transient	Signal ports	+/- 4 kV @ 2.5 kHz
	DC Power ports	+/- 4 kV
	AC Power ports	+/- 4 kV
	Earth ground ports	+/- 4 kV
Oscillatory	Signal ports	2.5 kV common mode @1 MHz
	DC Power ports	2.5 kV common, 1 kV differential mode @ 1 MHz
	AC Power ports	2.5 kV common, 1 kV differential mode @ 1 MHz
HV Impulse	Signal ports	5 kV (Fail-Safe Relay output)
	DC Power ports	5 kV
	AC Power ports	5 kV
Dielectric Strength	Signal ports	2 kV
	DC Power ports	2 kV
	AC Power ports	2 kV

>> Environmental Type Tests

Test	Description		Test Levels
IEC 60068-2-1	Cold Temperature	Test Ad	-40 °C (-40 °F), 16 Hours
IEC 60068-2-2	Dry Heat	Test Bd	85 °C (185 °F), 16 Hours
IEC 60068-2-30	Humidity (Damp Heat, Cyclic)	Test Db	95% (non-condensing), 55 °C (131 °F), 6 cycles
IEC 60255-21-1	Vibration		2 g @ 10 - 150 Hz
IEC 60255-21-2	Shock		30 g @ 11 mS

